

N°	Description	ED	Product	L2	L3	Status
1						NOT IN USE
2						NOT IN USE
3 (L2)	New modification for audio improvement on BE3 Level 2		BE3	X		IN USE
3 (L3)	New modification for audio improvement on BE3 Level 3		BE3		X	IN USE
4	Metallic dust in HE and BE products earpiece		HE –BE	X	X	IN USE
6	Utilisation des carte SIM « Bouygues »		TOUS	X	X	IN USE only FR
7	Reprise manuelle des batteries SAFT		BE1-BE3		X	IN USE only FR
8	Battery return procedure	03	BE	X	X	IN USE
9	Information about the shielding modification on BE1 and BE3 products		BE1-BE3	X	X	IN USE
10	Information about the ARIES shielding compatibility with the 3DSxxxxAHAG radiodigital board		BE1-BE3	X	X	IN USE
11	Information about the M09Z failure on the parametric / system test bench		BE1		X	IN USE
12	Information about the Audio modification on BE1 and BE3		BE1-BE3	X	X	IN USE
13	Information about autoreset or auto switch off during calls on BE1 and BE3		BE1-BE3		X	IN USE
14	Information about new 16Mb flashes on BE1 /BE3		BE1-BE3		X	IN USE
15	Elios Bench Fault Codes Level 3	01	BE		X	IN USE
16	Information about diagnosis of M360 failure on BE1 /BE3		BE1-BE3		X	IN USE
17	Information about differents faults codes on the parametric/system test bench		BE1-BE3		X	IN USE
18	Information about the M830, M831, M832 failures on the parametric / system test bench		BE1-BE3		X	IN USE
19	Elios Bench Fault Codes Level 2	01	BE	X		IN USE
20	Final Test parameters	01	BE	X	X	IN USE
21	Information about display error on BE3		BE3	X	X	NOT IN USE
22	Information about DCS power measurements in Final Test		BE1-BE3	X	X	IN USE
23	BE4 repairs		BE4	X	X	NOT IN USE
24	Information about network loss on BE1 and BE3		BE1-BE3		X	IN USE
25	Information about “Check SIM”failure on HE1 products		HE 1	X	X	NOT IN USE
26	List of components witch need a parametric system test		BE1-BE3		X	IN USE
27	Criteria acceptance for Alcatel Battery	01	Tous	X	X	IN USE
28	P/S erreur codes for BE	01	BE1-BE3-BE4		X	IN USE
29	Information about acksys customization	01	BE1	X	X	NOT IN USE
30	Information about vibrating battery cover modification	01	BE1-BE3	X	X	IN USE
31	Information about use of "CHECKER"for BE1 customization	01	BE1	X	X	IN USE
32 (L2)	Hardware upgrading improvement	01	BE1-BE3	X		IN USE
32 (L3)	Hardware upgrading improvement	01	BE1-BE3		X	IN USE
33	Information about RST failures on BE4 products	01	BE4	X	X	NOT IN USE
34	Information about swapping on BE4 products	05	BE4	X	X	IN USE
35	Information about Elios customization presentation screen	01	BE4	X	X	IN USE
36	Information about humidity stickers for warranty acceptance	01	BE4	X	X	IN USE
37	Information about BE4 repairs in L3 repair centers (weekly report)	01	BE4		X	NOT IN USE
38	Information about new database on BE4 products	02	BE4	X	X	IN USE

N°	Description	ED	Product	L2	L3	Status
39	Information about MA100 on BE4 products	01	BE4		X	IN USE
40	Information about WAP customisation on BE3 products	01	BE3	X	X	IN USE
41	Information about RST failures on BE4 products	01	BE4		X	NOT IN USE
42	Information about parametric system test on BE1 and BE4 products	01	BE1-BE4		X	IN USE
43	Information battery autonomy	01	BE5	X	X	IN USE
44	Information about use of "CHECKER"for BE4 customization	01	BE4	X	X	IN USE
45	Weekly BE5	01	BE5	X		IN USE
46	Information about RST failures on BE4 products	01	BE4		X	NOT IN USE
47	GSM measurements for BE4 and BE5	01	BE4-BE5	X	X	IN USE
48	Information about Humidity stickers on BE4 products	01	BE4	X	X	IN USE
49L2	Information about failures on BE4 products due to a defective BBG	02	BE4	X		IN USE
49L3	Information about failures on BE4 products due to a defective BBG	02	BE4		X	IN USE
50	Information about TPA and battery on BE5 products	02	BE5	X	X	IN USE
51	Information about addition sticker on BE4	01	BE4	X	X	Specific ACCORD
52	Information about positioning tool for BGA components used on PDR soldering machine	01	BE4		X	IN USE
53	Cloning software for BE5	03	BE5	X	X	IN USE
54	Addendum for BE5	01	BE5	X	X	IN USE
55	List of faulty components for Be4 and BE5	01	BE4-BE5	X	X	IN USE
56	List of BE4 board (With or without IMEI)	01	BE4			GEODIS
57	Perso des terminaux France Telecom	01	BE1-BE4-BE5	X	X	France
58	Perso des terminaux SFR	01	BE4	X	X	France
59	Information about elios customization	01	BE _x	X	X	IN USE
60	How recognize J904 connector on BE5	03	BE5	X	X	IN USE
61	Special customization for TIM	01	BE4	X	X	NOT IN USE
62	Information about NWK on BE4	01	BE4	X	X	IN USE
63	Information about earpiece on BE5	02	BE5	X	X	IN USE
64	Information about battery connector on BE5	02	BE5	X	X	IN USE
65	Information about warranty on BE5	01	BE5	X	X	IN USE
66	Information about mould F on BE5	01	BE5	X	X	IN USE
67	Information about discrepancy on BE5	01	BE5	X	X	IN USE
68	Information about network failure on BE5	01	BE5	X	X	IN USE
69	Information about "Hardware Upgrading" on BF4 products	01	BF4	X	X	IN USE
70	Information about "Charge connector" on BF4 products	03	BF4	X	X	NOT IN USE
72	Information about cosmetics problems on Bex	01	BE _x	X		IN USE
73	Information about "Customization database v2,3 on HE1 products	01	HE1	X	X	NOT IN USE
74	Information about BF3 battery	02	BF3	X	X	IN USE
75	Information about "Defective charge connector" on BF4 products	01	BF4	X	X	IN USE
76	Information about "BBG " on BF4 boards	01	BF4	X	X	IN USE
78	Information about "Customization on BE4, BF3, BF4 products	02	BF4	X	X	IN USE
80	Information about "Charge connector" on BF3 products	01	BF3	X	X	NOT IN USE
81	Information about autonomie failure on BE4 and BE5 products	01	BE4-BE5		X	IN USE

N°	Description	ED	Product	L2	L3	Status
82	Information about "empty battery" on BF4 products	01	BF4	X	X	IN USE
83	Information about use of "CHECKER"for BF4	01	BF4	X	X	IN USE
85	Information about "Board repair" on BE4 products	01	BE4		X	IN USE
86	Information about swapping BE5 board (16Mo)	01	BE5		X	IN USE
87	Information about Warranty on BF4 products	01	BF4	X	X	IN USE
88	Information about criteria acceptance battery on BE5	01	BE5	X	X	IN USE
89	Information about "Defective charge connector" on BF3 products	01	BF3	X	X	IN USE
90	Information about failures on BE4 products	01	BE4		X	IN USE
91	Information about failures on BE4 products	02	BE4	X		IN USE
92	Perso des terminaux BF3 SFR	01	BF3	X	X	IN USE only FR
93	Perso des terminaux BF3 France Telecom	01	BF3	X	X	IN USE only FR
94	Information about "antenna compatibility" on BF4 products	01	BF4	X	X	IN USE
95	Information about "charge connector" on BF4 products	01	BF4	X	X	IN USE
96	Information about fault code NWK on BF3 product	01	BF3	X	X	IN USE
97	Information interface parametic/system on BE5	01	BE5		X	IN USE
98	Information about "Warranty conditions" on ALCATEL products	01	ALL Products	X	X	IN USE
99	Information about "Key film on BF4 products"	01	BF4	X	X	IN USE
100	Information about use of "PCB TEST TOOL" on BF3/BF4 products	02	BF3/BF4	X	X	IN USE